# **Tutorial flask iot**

#### 1. install flask

in raspberry open terminal (alt+ctrl+t) and write script below into terminal sudo pip install flask

# 2. install opency


install opency in raspberry, follow this tutorial from <a href="https://gengineering.eu/install-opency-4.1-on-raspberry-pi-4.html">https://gengineering.eu/install-opency-4.1-on-raspberry-pi-4.html</a>


# 3. config camera and I2C

in raspberry open terminal (alt+ctrl+t) and write script below into terminal
sudo apt update
sudo apt full-upgrade

sudo raspi-config


Use the cursor keys to select and open *Interfacing Options*, and then select *Camera* and follow the prompt to enable the camera.







# **Enable I2C**



restart your raspberry pi, open again terminal and write script below into terminal.

```
raspistill -v -o test.jpg
```

check in pictures if there are a picture from camera your camera was connected. if the camera not found, test camera using cheese

```
sudo apt-get install cheese
and write
cheese
```

# 4. structure file

the root folder includes file py and html. if you start the program, make sure you are in the right path.

```
Activities Terminal pl@raspbe

File Edit View Search Terminal Help

pl@raspberrypi:~/Documents/flask_iot/flask $ tree

dht_11.py

flask_test_webcam.py

gy_302_BH1750.py

gy_302_BH1750.py

openweather.py

openweather.py

pycache

plask.cpython-37.pyc

templates

index.html

test

camera.py

dht_11.py

gy_302_BH1750.py

openweather.py

total test

camera.py

dht_11.py

gy-302_BH1750.py

openweather.py

t.jpg

3 directories, 13 files

pi@raspberrypi:~/Documents/flask_iot/flask $ []
```


#### 5. test camera

test camera using opency open folder test and open terminal. make sure you are in **test** folder before you write script bellow into terminal

```
python camera.py
```

if success the window will showing video from your camera and press q to exit if the window show error like picture below, try to change port from 0 or 1 or 2 or 3 in the file camera.py example

cap = cv2.VideoCapture(0) #try change value ini VideoCapture



#### 6. install library sensor dht-11


install library. open terminal and write script below


```
sudo apt-get install git-core
git clone https://github.com/adafruit/Adafruit_Python_DHT.git
cd Adafruit_Python_DHT
sudo apt-get install build-essential python-dev
sudo python setup.py install
```

## 7. test sensor dht-11

to test the sensor, make sure you are in **test** folder before you write script below into terminal

```
python dht 11.py
```








# 8. sensor gy-302

follow the configuration of sensor like picture bellow and make sure the cable has been installed properly





# 9. check your I2C connection

write script bellow into your terminal


lsmod | grep i2c\_



# then write script below into your terminal

sudo apt-get install i2c-tools
sudo i2cdetect -y 1


if you see the terminal show like picture bellow, your I2C has been connected



# 10. test sensor gy-302

to test sensor, make sure you are in **test** folder before you write script below into terminal. python gy-302\_BH1750.py

if you see the terminal like this



sensor has been worked


## 11. flask web dashboard

to start flask web service framework, make sure you are in the right path. the main program is in the flask folder by name **flask\_test\_webcam.py**. to start the program, open terminal and write script below into terminal

python flask\_test\_webcam.py



open link https into your browser. if no error, the browser will show dashboard like this



your dashboard monitoring ready to use